



정량펌프/정량토출기 설정 메뉴얼

- *기계를 켜고 맨위 노브를 누르시면 메뉴로 들어갑니다.
- *노브를 돌리시면 값이 변동됩니다.
- *설정을 바꿀시에 노브를 꼭 누르셔야 설정값이 저장됩니다.
- *공장초기화, 풋스위치 수동설치시 순서에 따라 설정하셔야 합니다.

[CALLIBRATION & SETTING]- F0/F1/F2 메뉴항목은 토출 관련으로 M 시리즈는 포함되지 않습니다.

- A0 모드 변경 select of direction controll - A0-0 ; *speed mode(rpm)* 1 A0-1 : *flow mode(ml/min)*
- F1 인터벌 시간 interval time (stop time)
- F2 반복 횟수 filling number

[A0-1모드(FLOW MODE)시 헤드와 튜브 세팅, 보정을 기본적으로 해주셔야 합니다.]

- A2-0 헤드선택 select head
- A2-1 튜브선택 select tube
- E0 액체 보정 calibration liquid

[TRANSFER]

- A1-0 ► Co-4
- A1-1 ► C1-0 방향 조정 select of direction controll - c1-0 ; *direction controlled by machine* 1 c1-1 : *direction controlled by external control*
- A1-2 ► C2-1 시작/중지 조정 select of start/stop controll - c2-0 ; *start&stop controlled by machine* 1 c2-1 ; *start&stop controlled by footswitch(external signal)*
- A1-3 ► C3-1 투입타입 injection type by external signal - c3-0 ; *gate type(level mode)* 1 c3-1 ; *trigger type (pulse mode)*
- A1-4 ► C4-0
- A1-5 ► C5-0
- A1-6 ► 9600
- A1-7 ► 1
- A1-8 ► 10 rpm 백석선 속도조절 suckback speed menu
- A1-9 ► 0 백석선 각도 조절 suckback angle manue
- A1-o ► Co-0

A1-b ► Cb-4

A1-d ► Cd-0

[DISPENSING]

F0 주입시간 filling time

F1 인터벌 시간 interval time (stop time)

F2 반복 횟수 filling number



공장 초기화 세팅

공장 초기화 세팅

*차례대로(윗줄→아랫줄) 순서를 지켜주셔야 합니다.

*펌프 후면에 풋스위치 연결을 해제하고 펌프에서 설정한뒤 연결선을 꽂아주셔야 합니다.

*구매하신 펌프는 기본 풋스위치 자동세팅이 되어있습니다.

A1-C ▶ Cc-0 공장초기화 세팅 back to the factory setting
A1-0 ▶ Co-4
A1-1 ▶ C1-0
A1-2 ▶ C2-1
A1-3 ▶ C3-1
A1-4 ▶ C4-0
A1-5 ▶ C5-0
A1-6 ▶ 9600
A1-7 ▶ 1
A1-8 ▶ 10 rpm
A1-9 ▶ 0
A1-o ▶ Co-0
A1-b ▶ Cb-4
A1-d ▶ Cd-0



풋스위치 수동 설정 방법

풋스위치 수동 설정 방법

*차례대로 순서를 지켜주셔야 합니다.

*펌프 후면에 풋스위치 연결을 해제하고 펌프에서 설정한뒤 연결선을 꽂아주셔야 합니다.

*구매하신 펌프는 기본 풋스위치 자동세팅이 되어있습니다.

A1-0 ► Co-4

A1-1 ► C1-0 방향 조정 select of direction controll - *c1-0; direction controlled by machine* 1 *c1-1; direction controlled by external control*

A1-2 ► C2-1 시작/중지 조정 select of start/stop controll - *c2-0; start&stop controlled by machine* 1 *c2-1; start&stop controlled by footswitch(external signal)*

A1-3 ► C3-1 투입타입 injection type by external signal - *c3-0; gate type(level mode)* 1 *c3-1; trigger type (pulse mode)*

A1-4 ► C4-0

A1-5 ► C5-0

A1-6 ► 9600

A1-7 ► 1

A1-8 ► 10 rpm 백섹션 속도조절 suckback speed menu

A1-9 ► 0 백섹션 각도 조절 suckback angle manue

A1-o ► Co-0

A1-b ► Cb-4

A1-d ► Cd-0